



Team846 /  
macaque



<> Code

Issues

Pull requests

Actions

Projects

Security

Insights

# Commit

## April Tag Odometry Relocalization

Browse files

master

kGoel647 committed 20 hours ago

1 parent [3c06b4c](#) commit [b65b3a0](#)

Showing 2 changed files with 58 additions and 0 deletions.

Whitespace

Ignore whitespace

Split

Unified

46 src/y2024/cpp/subsystems/drivetrain.cc

```
185     readings.pose.bearing =  
        units::degree_t(gyro_.GetYaw()) +  
        bearing_offset_;  
186     readings.angular_velocity =  
        units::degrees_per_second_t(gyro_.GetRate(  
        ));  
187
```

```
185     readings.pose.bearing =  
        units::degree_t(gyro_.GetYaw()) +  
        bearing_offset_;  
186     readings.angular_velocity =  
        units::degrees_per_second_t(gyro_.GetRate(  
        ));  
187  
188 + // April Tag Information Receiving  
189 + units::second_t  
        receivedAprilTagFrameTime =  
        units::second_t(  
190 +     aprilTag_table-  
        >GetEntry("aprilTagFrameTime").GetDouble(-  
        1.0));  
191 + if (receivedAprilTagFrameTime!=  
        aprilTagFrameTime){  
192 +     poseAtFrameCapture=odometry_.pose();  
193 +  
        aprilTagFrameTime=receivedAprilTagFrameTim  
        e;  
194 +     updatedTagPos=false;  
195 + }  
196 + bool processedFrame = aprilTag_table-  
        >GetEntry("processedFrame").GetBoolean(fal  
        se);
```

```

188     auto pitch_initial =
units::degree_t(gyro_.GetPitch());
189     auto roll_initial =
units::degree_t(gyro_.GetRoll());
190     auto tilt =
232
233     readings.velocity = unfiltered_velocity;
234





```

```

197 +   frc846::Vector2D<units::foot_t>
robotPoint;
198 +   robotPoint.x =
199 +       units::foot_t(aprilTag_table-
>GetEntry("robotX").GetDouble(-1.0)) +
200 +       5.25_in;
201 +   robotPoint.y =
202 +       units::foot_t(aprilTag_table-
>GetEntry("robotY").GetDouble(-1.0)) -
8_in;
203 +   units::foot_t
tagDistance=robotPoint.Magnitude();
204 +   auto aprilTagX =
205 +       units::foot_t(aprilTag_table-
>GetEntry("aprilTagX").GetDouble(-1.0));
206 +   auto aprilTagY =
207 +       units::foot_t(aprilTag_table-
>GetEntry("aprilTagY").GetDouble(-1.0));
208 +   double aprilTagConfidence =
209 +       aprilTag_table-
>GetEntry("aprilTagConfidence").GetDouble(
0.0);
210 +   auto aprilTagID = aprilTag_table-
>GetEntry("aprilTagID").GetDouble(-1.0);
211 +
212 +   // April Tag Pose Calculations, etc.
213 +   if (aprilTagConfidence != 0) {
214 +       robotPoint =
robotPoint.Rotate(readings.pose.bearing);
215 +       robotPoint.x = robotPoint.x -
aprilTagX;
216 +       robotPoint.y = robotPoint.y -
aprilTagY;
217 +   }
218 +
219 +
220     auto pitch_initial =
units::degree_t(gyro_.GetPitch());
221     auto roll_initial =
units::degree_t(gyro_.GetRoll());
222     auto tilt =
264
265     readings.velocity = unfiltered_velocity;
266
267 +   double aprilTagFactor=-1.0;
268 +   if (!updatedTagPos){
269 +       units::degree_t angleToTag =
units::math::atan2(aprilTagY-robotPoint.y,
aprilTagX-robotPoint.x);

```

		<pre> 270 +     aprilTagFactor = aprilTagConfidence *       confidence_factor.value() * 271 +         (1 -       (readings.velocity.Magnitude()/max_speed_.       value())) * 272 +     velocity_factor.value() *       (1/(tagDistance.to&lt;double&gt;       ())) * distance_factor.value() * (90_deg-       units::math::abs(readings.pose.bearing-       angleToTag)).to&lt;double&gt;       ())*angle_offset_factor.value(); 273 + 274 +     frc846::Vector2D&lt;units::foot_t&gt; point; 275 +     point.x =       (((poseAtFrameCapture.point.x +       aprilTagFactor * robotPoint.x) / (1 +       aprilTagFactor)) +       odometry_.pose().point.x-       poseAtFrameCapture.point.x); 276 +     point.y =       (((poseAtFrameCapture.point.y +       aprilTagFactor * robotPoint.y) / (1 +       aprilTagFactor))+       odometry_.pose().point.y-       poseAtFrameCapture.point.y); 277 +     odometry_.SetPoint(point); 278 +     updatedTagPos=true; 279 + } 280 + 281 </pre>
235	pose_x_graph_.Graph(odometry_.pose().point.x);	pose_x_graph_.Graph(odometry_.pose().point.x);
236	pose_y_graph_.Graph(odometry_.pose().point.y);	pose_y_graph_.Graph(odometry_.pose().point.y);
237	pose_bearing_graph.Graph(odometry_.pose().bearing);	pose_bearing_graph.Graph(odometry_.pose().bearing);



**12**

src/y2024/include/subsystems/drivetrain.h


159	bool VerifyHardware() override;	159	bool VerifyHardware() override;
160		160	
161	private:	161	private:
		162	+ //April Tag
		163	+ units::second_t aprilTagFrameTime;
		164	+ frc846::Position poseAtFrameCapture;
		165	+ bool updatedTagPos=false;

```

162 // Drivetrain dimensions.
163 frc846::Pref<units::inch_t>
width_{*this, "width", 21.75_in};
164 frc846::Pref<units::inch_t>
height_{*this, "height", 26.75_in};

```

```

166 + frc846::Loggable
    april_tags_loggable_{*this, "april_tags"};
167 + frc846::Pref<double>
    confidence_factor{april_tags_loggable_,
    "april_confidence_factor", 1.0};
168 + frc846::Pref<double>
    velocity_factor{april_tags_loggable_,
    "april_velocity_factor", 1.0};
169 + frc846::Pref<double>
    distance_factor{april_tags_loggable_,
    "april_distance_factor", 1.0};
170 + frc846::Pref<double>
    angle_offset_factor{april_tags_loggable_,
    "april_angle_factor", 1.0};
171 +
172 + std::shared_ptr<nt::NetworkTable>
    aprilTag_table =
173 +
    nt::NetworkTableInstance::GetDefault().Get
    Table("AprilTags");
174 // Drivetrain dimensions.
175 frc846::Pref<units::inch_t>
width_{*this, "width", 21.75_in};
176 frc846::Pref<units::inch_t>
height_{*this, "height", 26.75_in};

```

0 comments on commit [b65b3a0](#)


Write

Preview

H B I ≡ <> 🔗 | ½ ≡ ≡ ≡ | 📎 @ ↗ ↶

Leave a comment

 Markdown is supported

 Paste, drop, or click to add files

[Comment on this commit](#)